Pro Team Baseball Youth Jersey

WHITE / MAROON

No PMS / 7643C

No PMS 539C

No PMS /



No PMS / tle darker t

No PMS

36C & 7687



Due to the nature of polyester, special care must be taken throughout the decoration process.

No PMS / 200C

No PMS / 7736C

Y3526 - ATC[™] Pro Team Baseball Youth Jersey

GARMENT MEASUREMENTS						
Size	S	М	L	XL		
Chest - Half Measure	16 1/2"	17 1/2"	18 1/2"	20"		
Chest - Full Measure	33"	35"	37"	40"		
Body Length from HPS	22 3/4"	24 1/4"	26 1/4"	28 1/4"		
Sleeve Length from HPS	20 1/4"	21 1/4"	22 1/4"	23 1/4"		
Einished measurements in inches Peter to "How to Measure" nuide for detailed information on measurement instructions						

shed measurements in inches. Refer to "How to Measure" guide for detailed information on measurement instructions.

YOUTH General Sizing Guide

TOUTH General Sizing Guide					
Size	S	М	L	XL	
Numeric Size	6-8	10-12	14-16	18-20	
Chest	26"-28"	28"-30"	30"-32"	32"-35"	
Waist	23"-24 1/2"	24 1/2"-25 1/2"	25 1/2"-27"	27"-29"	
Sleeve Length-CB	25"-26"	26"-27 1/2"	27 1/2"-29"	29 1/2"-31"	

ATC AUTHENTIC T-SHIRT COMPANY*

DECORATING INSTRUCTIONS FOR NO BLEED POLYESTER FABRICS

Due to the nature of polyester, special care must be taken throughout the decoration process. Here are some tips to effectively decorate our no bleed performance products.

- Garment temperature must not exceed 320°F or 160°C. Exceeding this temperature will cause the fabric to shrink, become wavy or cause dye migration.
- Dryer temperature and belt speeds must be changed accordingly for polyester fabric.
- If flashing these garments, do not exceed 1-2 seconds. Anything longer may damage the fabric as stated above.
- Screen Printing: These garments require the use of poly inks that cures at a lower temperature. Please consult your ink supplier for more information.
- Polyester requires a longer cooling time than cotton. Avoid overlap of garments and screen-print/heat transfer until the garments are cooled. Failure to cool the fabric prior to stacking into a printer's fold may cause the fabric and applied ink to stick together.
- Heat Transfers: If you heat press these garments, you must adjust the time, temperature and pressure. Failure to do so may damage the fabric as stated above.
- Sublimation Printing: This process can only be done on white or very light colour shirts. Inks used in printing paper design needs to be darker than the base fabric or colour will migrate with the fabric colour resulting in a bleeding effect.

• A test sample run is recommended, especially if you have a large order or if your printer does not specialize in printing on performance fabrics.